



Next Floor Floating Floor Stair Installation Guide

Make sure that the attached cushion is firmly and completely attached to the planks to be installed on the stair treads (and risers if applicable). If it is not, either remove the cushion or reattach it with a Premium Polyurethane Construction (PUR) Adhesive. Use the PUR Adhesive to install the planks on the individual stair treads or risers.

The nosing on the TOP STEP (landing) should be installed as follows:



Step 1

Install the riser flush to the stair. Cut a 1" wide strip of your floor. Drill, counter-sink, screw and glue it flush to the stair riser. Install flooring 0.25" from the glued down 1" strip. **DO NOT glue flooring down.** Clean flooring and molding as directed below:

CLEANING PREPARATION FOR BOTH SURFACES

Preparing the floor & molding as outlined is mandatory to achieve the required bonding strength


1. Use a damp cloth (water only) to clean both surfaces of loose particles or surface films.
2. Roughen the surfaces with sandpaper (100-150 grit), sanding sponge or metal brush.
3. Degrease both surfaces to remove all traces of oil, grease, dust, and fingerprints by using a light solvent such as isopropyl alcohol (refer to the manufacturer's recommendations for additional safe cleaning agents).
4. Let both surfaces dry thoroughly before applying adhesive.

Step 2



Turn the molding after following the cleaning preparation above. **DO NOT peel the release paper off of the adhesive tape.**

Step 3

Next, apply a generous bead of a Premium Polyurethane Construction Adhesive along the entire inside corner. Be sure to **NOT** overlap the tape with the adhesive.




Underside of the molding generously covered with PUR Adhesive



Step 4

Touch the bottom of molding to the stair riser and carefully roll the stair nose in place. Make any final adjustments before you push the molding all the way down. Once it's in the final position, press down firmly with your hands and make your way down the entire stair nose. It may take 2 or 3 passes to set it firmly in place.





Step 5

Let the adhesive cure for at least 4 hours before any walking on it. For exposure to full traffic, wait 24 to 48 hours.

NOTE: Complete cure takes 48 hours.

Next Floor Floating Floor Stair Installation Guide

The NOSINGS on the stair treads should be installed as follows:



**The purpose of the double-sided tape is to secure the molding firmly in place until the premium polyurethane construction adhesive totally cures.*


Step 1

Install the riser flush to the stair. Glue down flooring planks (refer to note on the previous page regarding attached cushion). Then, clean flooring and molding as directed below:

CLEANING PREPARATION FOR BOTH SURFACES

Preparing the floor & molding as outlined is mandatory to achieve the required bonding strength

1. Use a damp cloth (water only) to clean both surfaces of loose particles or surface films.
2. Roughen the surfaces with sandpaper (100-150 grit), sanding sponge or metal brush. For flooring, only roughen up area that will be covered (1.25" to 1.5").
3. Degrease both surfaces to remove all traces of oil, grease, dust, and fingerprints by using a light solvent such as isopropyl alcohol (refer to the manufacturer's recommendations for additional safe cleaning agents).
4. Let both surfaces dry thoroughly before applying adhesive.




Step 2



Turn the molding over and roughen the inside surface of the molding to increase bond by means of 100-150 grit sandpaper, sanding sponge, or metal brush. For flooring, only roughen up area that will be covered. Then, gently peel the release paper all the way off the adhesive tape.

Step 3

Next, apply a generous bead of a Premium Polyurethane Construction Adhesive along the entire inside corner. Be sure to overlap the tape with the adhesive.




Underside of the molding generously covered with PUR Adhesive



Step 4

Touch the bottom of molding to the stair riser and carefully roll the stair nose in place. Make any final adjustments before you push the molding all the way down. Once it's in the final position, press down firmly with your hands and make your way down the entire stair nose. It may take 2 or 3 passes to set it firmly in place.



Step 5

Let the adhesive cure for at least 4 hours before any walking on it. For exposure to full traffic, wait 24 to 48 hours.

NOTE: Complete cure takes 48 hours.

Note: Installing over existing flooring on stairs is not permitted. Existing flooring must be removed, and stair substrate must be flat (level), smooth and solid (no deflection).